

How to install the USB-driver?

SSP Safety System Products
GmbH & Co. KG
Max-Planck-Straße 21
DE-78549 Spaichingen
Telefon: +49 7424 98 049-0
Telefax: +49 7424 98 049-99



1. Download the driver file and unzip it (**Password: a**).
2. Connect Simplifier to one USB port.
3. Open device manager and find the Simplifier unit.
4. Right click and choose "Update Driver Software" or similar.
5. Click "Browse my computer for driver software".
6. Click "Let me pick from a list of device drivers on my computer".
7. Click "Have Disk" and navigate to where you downloaded the file, and select it.
8. Click Next. (Windows might warn about the driver not being signed, continue anyway).
9. Wait. The installer can take around 5-10 minutes. Do not close it.
10. When it is finished, test it with Simplifier Manager. If the driver is installed correctly, the information of the connected unit will display in the download window in Simplifier Manager.